



Maintenance:

Periodically inspect fabric for unusual wear, especially on the edges since the fabric roll could be telescoping into the brackets, and call for service before damage is severe.

Cleaning Instructions for Phifer SheerWeave and PVC coated Fabrics:

The following cleaning practices will not affect the products' ability to resist the growth of microorganisms.

- Clean with mild soap and water.
- If cleaners other than mild soap and water are desired, test in an inconspicuous area, prior to use.
- Avoid strong cleaners and disinfectants, especially those containing quaternary ammonium compounds and phenols.
- Rinse thoroughly after cleaning.

Paint solvents will damage the vinyl surface of the SheerWeave products and should not be used.

Cleaning Instructions for PVC-Free Sheer and PVC-Free Blackout Fabrics:

- Remove dust with vacuum cleaner or compressed air.
- Do not scrub.
- Do not use solvents or any abrasive substance which might damage the coating of the fabric.
- For spot removal a special dry cleaning sponge may be gently used. Made of vulcanized natural rubber, the sponges are non-greasy, leave no residue and are completely safe for use on delicate fabrics.
- If cleaners other than what is mentioned above are desired, test in an inconspicuous area, prior to use.

Skyco Shading Systems, Inc.

3411 West Fordham Ave
Santa Ana, CA 92704-4422
1-800-777-5926
Voice (714) 708-3038
Fax (714) 708-3053
www.skycoshade.com